


PART NUMBER & ASSEMBLY DRAWING

TYPE : AQR05-00



PART NO. Q'NTY NAME/DESCRIPTIONS

NO.	PART NO.	Q'NTY	NAME/DESCRIPTIONS
1	AQR05-01A		GEARBOX ASSEMBLY FRAME/GEARBOX NUTS/INSERT NUTS/INSERT
	AQR05-011		
	AQR05-012		
	AQR05-013		
2	AQR05-02A		BOTTOM COVER ASSY BOTTOM COVER/GEARBOX BEARING/BOTTOM GEAR PIN GEAR PIN /COUPLING GEAR PIN FOR GEAR RELEASER
	AQR05-021		
	AQR05-022		
	AQR05-023		
	AQR05-024		
	AQR05-026		
3	AQR05-03A		NO.1 GEAR NO.1 GEAR NO.2 GEAR NO.3 GEAR ASS'Y NO.3 GEAR NO.3 GEAR SPINDLE NO.4 GEAR NO.4 GEAR ASS'Y NO.5 GEAR NO.5 GEAR SPINDLE NO.6 GEAR/SLIDE DRIVER No.7 GEAR PUSH-UP SPRING GEAR RELEASER
	AQR05-031A		
	AQR05-031B		
	AQR05-032		
	AQR05-033A		
	AQR05-0330		
	AQR05-0331		
	AQR05-034		
	AQR05-035A		
	AQR05-0350		
	AQR05-0351		
	AQR05-0352		
	AQR05-036		
	AQR05-037		
AQR05-038			
4	AQR05-04A		COUPLING ASSY Drum gear-A Drum gear-B Drum gear-C STEEL RING PLUG/SPARE MAGNETIC RING GUIDE MAGNETIC RING -PM100 MAGNETIC RING -BM-1200 MAGNETIC RING -BM-1500 MAGNETIC RING -BM-1750 COUPLING PLUG
	AQR05-041A		
	AQR05-041B		
	AQR05-041C		
	AQR05-042		
	AQR05-043A		
	AQR05-043B		
	AQR05-044A		
	AQR05-044B		
	AQR05-044C		
	AQR05-044D		
	AQR05-045		
	AQR05-051		
	AQR05-052		
5	AQR05-05A		ROTATING OUT GEAR ASSY BOTTOM BEARING TOP BEARING OUTPUT GEAR-A OUTPUT GEAR-B OUTPUT GEAR-C BASE-OUTPUT GEAR-C SLICED GEARS COUPLER SET BOLT U-BOLT CLAMP OUTPUT UNIT U-COUPPLER POWER GRIP PIECES U-BOLT WASHERS NUTS SNAP RING
	AQR05-0511		
	AQR05-0512		
	AQR05-0520		
	AQR05-0530		
	AQR05-054A		
	AQR05-0541		
	AQR05-0542		
	AQR05-0551		
	AQR05-0552		
	AQR05-058A		
	AQR05-0584		
	AQR05-0583		
	AQR05-0580		
AQR05-0581			
AQR05-0582			
AQR05-0583			
AQR05-0584			
AQR05-0585			
6	AQR05-06A		UPPER COVER ASSY/GEARBOX UPPER COVER/GEARBOX TOP BEARING
	AQR05-061		
	AQR05-062		
	AQR05-063		
7	AQR05-07A		BASE ASSY/DRIVE MOTOR BASE/DRIVE MOTOR MOUNTING SCREWS FEEDBACK CARRIER CABLE ENTRY PLUG FLEX-CONNECTOR
	AQR05-071		
	AQR05-072		
	AQR05-073		
	AQR05-074		
8	AQR05-08A		SQR65.10 PCB ASSY SQR65.10 PCB FINGER TIP CONTACT MOUNTING SCREWS
	AQR05-081		
	AQR05-082		
	AQR05-083		
9	AQR05-09A		PROTECT COVER ASSY PROTECT COVER
	AQR05-091		
10	AQR05-10A		DRIVE MOTOR ASSY DRIVE MOTOR/SYNCHRONOUS LEAD CONNECTOR DRIVE KEY NUT O-RING/RUBBER CENTERING RING
	AQR05-101		
	AQR05-102		
	AQR05-103		
	AQR05-104		
	AQR05-105		
	AQR05-106		
11	AQR05-11A		MOTOR FIXING CLAMP ASSY FIXING SCREWS
	AQR05-111		
	AQR05-112		
	AQR05-113		
12	AQR05-12A		COVER ASSY/DRIVE MOTOR COVER/DRIVE MOTOR RELEASE BUTTON FIXING I-BOLT
	AQR05-121		
	AQR05-122		
	AQR05-123		
13	AQR05-013A		SPRING PACK ASSY
	AQR05-131		
	AQR05-132		
	AQR05-133		
	AQR05-134		
	AQR05-135		
	AQR05-136		
	AQR05-137		
	AQR05-138		
	AQR05-139		
14	AQR05-012		AQR05-01A
	AQR05-011		
	AQR05-038		
	AQR05-037		
	AQR05-0351		
	AQR05-0354		
AQR05-03A	AQR05-0352		
	AQR05-0353		
	AQR05-0350		
	AQR05-034		
	AQR05-036		
	AQR05-031B		
AQR05-02A	AQR05-0331		
	AQR05-0330		
	AQR05-0332		
	AQR05-033A		
	AQR05-031A		
	AQR05-032		
AQR05-02A	AQR05-021		
	AQR05-022		
	AQR05-026		
	AQR05-024		